





# LTE router **LR77 v2** and **LR77 v2 SL**


## USER'S GUIDE



## Used symbols

 Danger – important notice, which may have an influence on the user's safety or the function of the device.

 Attention – notice on possible problems, which can arise in specific cases.

 Information, notice – information, which contains useful advice or special interest.

## GPL license

Source codes under GPL license are available free of charge by sending an email to [info@conel.cz](mailto:info@conel.cz).



**Declared quality system  
ISO 9001**





## Contents

1.Safety instruction	1
2.Product disposal instructions	2
3.Router description	3
4.Contents of package	4
5.Router design	5
5.1.Version	5
5.2.Delivery identification	5
5.3.Ordering code	6
5.3.1.Basic version	6
5.3.2.Full version	6
5.4.Basic dimensions plastic box	7
5.5.Basic dimensions metal box	7
5.6.Mechanical external dimensions and mounting recommendations	8
5.7.User interfaces (connectors)	10
5.7.1.Status indication	11
5.7.2.Power connector PWR	12
5.7.3.Antenna connector ANT and AUX	13
5.7.4.SIM card reader	14
5.7.5.Ethernet port	14
5.7.6.PORT1	16
5.7.7.PORT2	16
5.7.8.USB port	17
5.7.9.I/O port	18
5.7.10.Reset	19
6.First use	20
6.1.Connecting the router before first use	20
6.2.Start router	21
6.3.Router configuration	21
6.3.1.Configuration over web browser	21
6.3.2.Configuration over Telnet	21
7.Technical parameters	22
7.1.Technical parameters of router	22
7.2.Technical parameters of module	22
7.3.Technical parameters of processor	23
7.4.Technical parameters I/O port	23
7.5.Technical parameters of expansion port	23
8.Recommended literature	24
9.Possible problems	24
10.FAQ	25
11.Customers support	27

## Image list

Fig. 1: Contents of package	4
Fig. 2: Front panel LR77 v2B	5
Fig. 3: Front panel LR77 v2B SL	5
Fig. 4: Front panel LR77 v2F	5
Fig. 5: Front panel LR77 v2F SL	5
Fig. 6: Label LR77 (Preliminary sample)	5
Fig. 7: Label LR77 SL (Preliminary sample)	5
Fig. 8 Basic dimensions plastic box	7
Fig. 9: Basic dimensions metal box	7
Fig. 10: Space around the antenna	8
Fig. 11: Space around antenna for SL version	8
Fig. 12: Cable routing	9
Fig. 13: Cable routing for SL version	9
Fig. 14: Space in front connectors	9
Fig. 15: Space in front connectors SL version	9
Fig. 16: Front panel LR77 v2F	10
Fig. 17: Front panel LR77 v2F SL	10
Fig. 18: Power connector	12
Fig. 19: Connection of power supply connector	12
Fig. 20: Connection of power supply	12
Fig. 21: External antenna	13
Fig. 22: Connecting the antenna	13
Fig. 23: Ejected the SIM card	14
Fig. 24: Ethernet connector	14
Fig. 25: Connection Ethernet cable	15
Fig. 26: Example of router connection	15
Fig. 27: Connection PORT1 cable	16
Fig. 28: Connection PORT2 cable	16
Fig. 29: USB connector	17
Fig. 30: Connection PLC to the router	17
Fig. 31: Connection flash memory to the router	17
Fig. 32: I/O connector	18
Fig. 33: Connection I/O cable	18
Fig. 34: Connection input and output of router	18
Fig. 35: Router reset	19
Fig. 36: Router connection	20

## Table list

Table 1: Expansion port possibilities	4
Table 2: Router version	5
Table 3: Delivery identification	5
Table 4: Ordering code of basic version	6
Table 5: Ordering code of full version	6
Table 6: Front panel description	10
Table 7: Router status indication	11
Table 8: Connection of power connector	12
Table 9: Connection of Ethernet connector	14
Table 10: Connection of USB connector	17
Table 11: Connection of I/O port	18
Table 12: Description of reset and restart router	19
Table 13: Technical parameters of router	22
Table 14: Technical parameters of module	22
Table 15: Technical parameters of processor	23
Table 16: Technical parameters of I/O port	23



## 1. Safety instruction

***Please, observe the following instructions:***

- The router must be used in compliance with all applicable international and national laws and in compliance with any special restrictions regulating the utilization of the router in prescribed applications and environments.
- To prevent possible injury to health and damage to appliances and to ensure that all the relevant provisions have been complied with, use only the original accessories. Unauthorised modifications or utilization of accessories that have not been approved may result in damage to the router and in a breach of applicable regulations. Unauthorized modifications or utilization of accessories that have not been approved may result in the termination of the validity of the guarantee.

- The router can not be opened.



- **Caution!** The SIM card could be swallowed by small children.
- It must not be exceeded by the maximum voltage 30V DC power connector on the router.
- Do not expose the router to extreme ambient conditions. Protect the router against dust, moisture and high temperature.
- The router should not be used at petrol stations of flammable and explosive materials. We remind the users of the duty to observe the restrictions concerning the utilization of radio devices at petrol stations, in chemical plants, or in the course of blasting works in which explosives are used.
- Switch off the router when travelling by plane. Utilization of the router in a plane may endanger the operation of the plane or interfere with the mobile telephone network, and may be unlawful. Failure to observe these instructions may result in the suspension or cancellation of telephone services for the respective client, or, it may result in legal sanctions; it may also result in both eventualities.
- When using the router in the close proximity of personal medical devices, such as cardiac pacemakers or hearing aids, you must proceed with heightened caution.
- If it is in the proximity of TV sets, radio receivers and personal computers, the telephone may cause interference.
- It is recommended that you should create an appropriate copy or backup of all the important settings that are stored in the memory of the device.



# PRODUCT DISPOSAL INSTRUCTIONS

## 2. Product disposal instructions

The WEEE (Waste Electrical and Electronic Equipment: 2002/96/EC) directive has been introduced to ensure that electrical/electronic products are recycled using the best available recovery techniques to minimize the impact on the environment. This product contains high quality materials and components which can be recycled. At the end of its life this product **MUST NOT** be mixed with other commercial waste for disposal. Check the terms and conditions of your supplier for disposal information.

### 3. Router description

LTE router LR77 v2 is used to wirelessly connect various equipments and devices via Ethernet interface 10/100 to the Internet or intranet. Thanks to high data transfer speed of up to 100 Mbit/s (download) and upload speed up to 50 Mbit/s it is an ideal wireless solution for traffic and security camera systems, individual computers, LAN networks, automatic teller machines (ATM) and other self-service terminals, etc.

As a standard, this exceptionally fast LTE LR77 v2 wireless router is equipped with one Ethernet 10/100, one USB Host port, one binary Input/output (I/O) port and one SIM card. To save and backup communication data a version with two SIM cards is available. The wide range of interface options of the LTE router further expands [expansion Port1 and Port2](#) - selected by the customer – for example Ethernet port 10/100, serial interface ports RS232/RS485/RS422/MBUS or (I/O – CNT). Port2 may be equipped with serial interfaces RS232/RS485/RS422/MBUS or (I/O – CNT). Both of ports can be fitted with internal switch XC-SW. This LTE wireless router is supplied either in a plastic or metal casing, based on the requirements of the customer.

Configuration is done via web interface protected by password. The LR77 v2 router supports creation of VPN tunnels using technologies IPsec, OpenVPN and L2TP to ensure safe communication. Web interface provides detail statistics about the 3G router activities, signal strength, detailed log, etc. Cellular router supports functions: DHCP, NAT, NAT-T, DynDNS, NTP, VRRP, control by SMS and many other function.

Other diagnostic functions ensuring continuous communication include automatic inspection of PPP connection offering an automatic restart feature – in case of connection losses, or hardware watchdog which monitors the status of the router. With the help of a special window (start up script window) you may insert Linux scripts for various actions. For some applications the key option to create several different configurations for one LTE wireless router, the so-called profiles (maximum of 4), and the option to switch between them (for example via SMS, binary input status, etc.) is essential. Cellular wireless routers LR77 v2 may automatically upgrade configuration and firmware from server. This allows mass reconfiguration of many routers in one time.

For easy use additional software may be used - communication VPN server Digiccluster and software for router monitoring [R-SeeNet](#).



#### Examples of possible applications

- mobile office
- fleet management
- security system
- telematic
- telemetric
- remote monitoring
- vending and dispatcher machines



## 4. Contents of package



Basic delivered set of router includes:

- router,
- power supply,
- crossover UTP cable,
- two external antennas,
- clips for the DIN rail,
- installation CD containing instructions,
- paper start guide.



Fig. 1: Contents of package

The router box and DIN mount are supplied in a metal case in the SL version of the router.



The router can also be supplied as expansion accessories:

- one or two expansion ports RS232, RS485/RS422, ETHERNET, M-BUS, CNT or XC-SW. Separation columns for mounting expansion boards are included.

### Module can be connected only as follows.

PORT1	RS232, RS485/422, ETHERNET, M-BUS, CNT, XC-SW (together with PORT2)
PORT2	RS232, RS485/422, M-BUS, XC-SW (together with PORT1)

Table 1: Expansion port possibilities

## 5. Router design

### 5.1. Version

	Box	SIM1	SIM2	I/O	USB	PORT1	PORT2	ETH
LR77 v2B set	Plastic	✓		✓	✓	✓		✓
LR77 v2B SL set	Metal	✓		✓	✓	✓		✓
LR77 v2F set	Plastic	✓	✓	✓	✓	✓	✓	✓
LR77 v2F SL set	Metal	✓	✓	✓	✓	✓	✓	✓

Table 2: Router version




Fig. 2: Front panel LR77 v2B




Fig. 3: Front panel LR77 v2B SL




Fig. 4: Front panel LR77 v2F




Fig. 5: Front panel LR77 v2F SL

### 5.2. Delivery identification

Trade name	Type name	Other
LR77 v2B	LR-77-v2	Basic version
LR77 v2B SL	LR-77-v2	Basic version in the metal box
LR77 v2F	LR-77-v2	Full version
LR77 v2F SL	LR-77-v2	Full version in the metal box

Table 3: Delivery identification




Fig. 6: Label LR77 (Preliminary sample)



Fig. 7: Label LR77 SL (Preliminary sample)

## 5.3. Ordering code

### 5.3.1. Basic version

Expansion port	Ordering code
Version without expansion port	LR77 v2B set
Version with expansion Ethernet port	LR77 v2B set ETH
Version with expansion RS232 port	LR77 v2B set RS232
Version with expansion RS485 port	LR77 v2B set RS458
Version with expansion MBUS port	LR77 v2B set MBUS
Version with expansion CNT port	LR77 v2B set CNT

Table 4: Ordering code of basic version

### 5.3.2. Full version

Expansion port	Possible participation	Ordering code
Version without expansion port		LR77 v2F set
Version with expansion Ethernet port	PORT1	LR77 v2F ETH set
Version with expansion RS232 port	PORT1 a PORT2	LR77 v2F RS232 set
Version with expansion RS485 port	PORT1 a PORT2	LR77 v2F RS458 set
Version with expansion MBUS port	PORT1 a PORT2	LR77 v2F MBUS set
Version with expansion CNT port	PORT1	LR77 v2F CNT set
Version with expansion XC-SW port	PORT1 + PORT2	LR77 v2F SWITCH set

Table 5: Ordering code of full version

Second expansion port is written after first expansion port in the ordering code.

Example:

- Full version with Ethernet and RS232 port: **LR77 v2F ETH RS232 set.**
- Full version with Ethernet and RS232 port in metal cover:  
**LR77 v2F SL ETH RS232 set.**

## 5.4. Basic dimensions plastic box




Fig. 8 Basic dimensions plastic box

## 5.5. Basic dimensions metal box




Fig. 9: Basic dimensions metal box

## 5.6. Mechanical external dimensions and mounting recommendations



Mounting recommendations:

- possibility to be put on a work surface,
- DIN rail with clips CPD2 (Elpac clip SL for SL version) are included.

For the most of applications with a built-in router in a switch board it is possible to recognize two kinds of environments:

- no public and industry environment of low voltage with high interference,
- public environment of low voltage without high interference.

For both of these environments it is possible to mount router to a switch board, the following there is no need to have examination immunity or issues in connection with EMC according to EN 60439-1 ed.2:00 + A1:04.

For compliance of EN 60439-1 ed.2:00 + A1:04 specification it is necessary to observe next assembly of the router to the switch - board:



- for whip antennas we recommend to observe a distance of 6 cm from cables and metal surfaces on every side according to the next picture due to the elimination of interference, while using an external antenna except for the switch-board it is necessary to fit a lightening conductor,



- before mounting a router on sheet-steel we recommend using an external antenna,




Fig. 10: Space around the antenna




Fig. 11: Space around antenna for SL version



for every cables we recommend to bind the bunch according to the following picture, we recommend for this use:

- length of the bunch (combination of power supply and data cables) can be maximum 1,5 m, if the length of data cables exceeds 1,5 m or in the event of, the cable leads towards the switch - board, we recommend installing over - voltage protectors (surge suppressors),
- with data cables they mustn't carry cables with reticular tension ~ 230 V/50 Hz,
- all signals to sensors must be twisted pairs




Fig. 12: Cable routing




Fig. 13: Cable routing for SL version



- sufficient space must be left before individual connectors for handling of cables




Fig. 14: Space in front connectors




Fig. 15: Space in front connectors SL version



- for correct function of the router we recommend to use in the switch-board earth-bonding distribution frame for grounding of power supply of router, data cables and antenna,

## 5.7. User interfaces (connectors)

On the front panel is located:

Label	Connector	Description
PWR	2-pin	Connector for connection the power supply adapter.
ETH	RJ45	Connector for connection into the local computer network.
PORT1	RJ45	Connector for connection equipment over RS232, RS458/422, ETHERNET, M-BUS, CNT or XC-SW.
PORT2	RJ45	Connector for connection equipment over RS232, RS485/422, M-BUS or XC-SW (only FULL version).
ANT	SMA	Connector for connection main antenna.
AUX	SMA	Connector for connection diversity antenna.
USB	USB-A Host	Connector– for connection the devices with the router, USB supports equipments with PL-2303 and FTDI USB/RS232 converter.
I/O	3-pin	Connector for connection of the binary input and output.
SIM1	-	Holder for first SIM card.
SIM2	-	Holder for second SIM card (only FULL version).

Table 6: Front panel description




Fig. 16: Front panel LR77 v2F




Fig. 17: Front panel LR77 v2F SL

## 5.7.1. Status indication

About router status inform eight led indicators on the front panel and on every port are two LED indicators, which inform about port status.

Label	Color	State	Description
PWR	Green	Blinking On	Router is ready Starting of the router
GSM	Red	Blinking	Communication in progress
PPP	Yellow	1 x flash per second 2 x flash per second 3x flash per second	Signal strength is from –50 dBm to –69 dBm Signal strength is from –70 dBm to –89 dBm or difference between neighbours cells is exactly 3 dBm Signal strength is from –90 dBm to –113 dBm or difference between neighbours cells is smaller than 3 dBm
USR	Yellow	Function selected by user	
OUT	Green	On	Binary output active
IN	Green	On	Binary input active
ETH	Green	On Off	Selected 100 Mbit/s Selected 10 Mbit/s
ETH	Yellow	On Blinking Off	The network cable is connected Data transmission The network cable is not connected
PORT	Green	Description by port (viz. Technical specification of expansion port)	
PORT	Yellow	Description by port (viz. Technical specification of expansion port)	
SIM1	Yellow	On	SIM card 1 is active
SIM2	Yellow	On	SIM card 2 is active

Table 7: Router status indication



State indicate of PPP LED is updated every 10 seconds.



## 5.7.2. Power connector PWR

Panel socket 2-pin.

Pin number	Signal mark	Description
1	VCC (+)	Positive pole of DC supply voltage (+10 to +30 VDC)
2	GND (-)	Negative pole of DC supply voltage

Table 8: Connection of power connector




Fig. 18: Power connector

Power supply for router is required between +10 V to +30 V DC supply. Protection against reversed polarity without signaling is built into the router.

The power consumption during receiving is 1W. The peak power consumption during data sending is 5,5W. For correct operation it is necessary that the power source is able to supply a peak current of 600mA.



Connector on the power cable connects into the power connector on the router head and tightens locking screws (see figure below).




Fig. 19: Connection of power supply connector



### Circuit example:




Fig. 20: Connection of power supply



The positive pole VCC is marked by a red socket on the power.

## 5.7.3. Antenna connector ANT and AUX

The antenna is connected to the router using the SMA connector on the front panel.



The router can not operate without the main antenna connected labeled as ANT.

ANT connector used to connect the main antenna router. To connect the second antenna for diversity income is used second connector AUX.



Example of antenna:




Fig. 21: External antenna

The antenna with the SMA connector. The antenna is connected to screw the antenna connector SMA to SMA connector on the router head (see figure below).




Fig. 22: Connecting the antenna



Diversity antenna improves wireless features of router in weak signal strength.

## 5.7.4. SIM card reader

The SIM card reader for 3 V and 1.8 V SIM cards is located on the front panel of the router. To initiate the router into operation it is necessary to insert an activated SIM card with unblocked PIN in the reader. The SIM cards might be of different adjusted APN (Access Point Name).

### Changing the SIM card:

Press the small yellow button to eject the reader holder. Insert the SIM card into the reader holder and slide it in the reader (see figure below).




Fig. 23: Ejected the SIM card

## 5.7.5. Ethernet port

Panel socket RJ45.

Pin number	Signal mark	Description	Data flow direction
1	TXD+	Transmit Data – positive pole	Input/Output
2	TXD-	Transmit Data – negative pole	Input/Output
3	RXD+	Receive Data – positive pole	Input/Output
4	---	---	
5	---	---	
6	RXD-	Receive Data – negative pole	Input/Output
7	---	---	
8	---	---	

Table 9: Connection of Ethernet connector




Fig. 24: Ethernet connector



**ATTENTION! Port ETH is not POE (Power Over Ethernet) compatible!**



Ethernet cable plug into the RJ45 connector labeled as ETH (see figure below).




Fig. 25: Connection Ethernet cable



The ETH router connection:






Fig. 26: Example of router connection

## 5.7.6. PORT1

The PORT1 is equipped with one of the offered options ports. For PORT1 are available on the interface.

**PORT1** RS232, RS485/422, ETHERNET, M-BUS, CNT, XC-SW (together with PORT2)

 Description, connection and examples of expansion connection ports can be found in separate manuals expansion ports.

 PORT1 cable plug into the RJ45 connector labeled as ETH (see figure below).





Fig. 27: Connection PORT1 cable

## 5.7.7. PORT2

The PORT2 is equipped with one of the offered options ports. For PORT2 are available on the interface.

**PORT2** RS232, RS485/422, M-BUS, XC-SW (together with PORT1)

 PORT2 is fitted only in the FULL version of the router

 Description, connection and examples of expansion connection ports can be found in separate manuals expansion ports.

PORT2 cable plug into the RJ45 connector labeled as ETH (see figure below).




Fig. 28: Connection PORT2 cable

## 5.7.8. USB port

Panel socket USB-A.

Pin number	Signal mark	Description	Data flow direction
1	+5V	Positive pole of 5V DC supply voltage	
2	USB data -	USB data signal – negative pole	Input/Output
3	USB data +	USB data signal – positive pole	Input/Output
4	GND	Negative pole of DC supply voltage	

Table 10: Connection of USB connector



Fig. 29: USB connector



**Example of connecting devices with serial interface to the USB router:**




Fig. 30: Connection PLC to the router



**Example of connecting of USB flash disk to the USB router:**




Fig. 31: Connection flash memory to the router

## 5.7.9. I/O port

Panel socket 3pin.

Pin no.	Signal mark	Description	Data flow direction
1	BIN0	Binary input	Input
2	GND	Signal ground	
3	OUT0	Binary output	Output

Table 11: Connection of I/O port




Fig. 32: I/O connector

The user interface I/O is for processing of binary input signal and to control (settings) of binary output signal. Binary output is not switched to ground in the default configuration.

Maximum load binary output is 30V / 100mA. The constant current supplied by the binary input is 3 mA.



Connector I/O cable connect into the I/O connector on the router head and tighten locking screws (see figure below).




Fig. 33: Connection I/O cable



Circuit example of a binary input or output equipment with router:




Fig. 34: Connection input and output of router

## 5.7.10. Reset



It is important to distinguish between reset and reboot the router.

Action	Router behavior	Invoking events
Reboot	Turn off and then turn on router	Disconnect and connect the power. Press the <b>reboot</b> button in the web configuration.
Reset	Restore default configuration and to reboot the router.	Press RST button.

Table 12: Description of reset and restart router

After green LED starts to blink it is possible to restore initial settings of the router by pressing button RST on front panel. After press button RST it is restoration of default configuration and reboot (green LED will be on).



For pressing the RST button could be used a narrow screwdriver.




Fig. 35: Router reset



We recommend to backup your router configuration (see configuration manual), because after reset router set configuration to the initial state.



## 6. First use

### 6.1. Connecting the router before first use

Before you give up the router, it is necessary to connect all components needed for the operation of your applications and the SIM card must be inserted. (See bellow picture)

The router can not operate without connected antenna, SIM card and power supply.

In operation, the router must be connected to the antenna, otherwise damage to the router.





Fig. 36: Router connection

## 6.2. Start router

The router is set up connecting the power supply to the router. In the default setting the router starts to login automatically to the preset APN. Device on the Ethernet port DHCP server will assign addresses. The behavior of the router can be modified by means of the web or Telnet interface, which is described in the configuration manual.


The power consumption during receiving is 1W. The peak power consumption during data sending is 5,5W. For correct operation it is necessary that the power source is able to supply a peak current of 600mA.

## 6.3. Router configuration

 **Attention!** If the SIM card is not inserted in the router, then it is impossible to operate. The inserted SIM card must have activated LTE/HSPA+/UMTS/EDGE/GPRS.


### 6.3.1. Configuration over web browser

Monitoring of the status, configuration and administration of the router can be performed by means of the web interface, which is available after insertion of IP address of the router into the web browser. The default IP address of the router is 192.168.1.1. Configuration may be performed only by the user "root" with initial password "root".

 A detailed description of the router settings via the Web interface can be found in the configuration manual.

### 6.3.2. Configuration over Telnet

Monitoring of status, configuration and administration of the router can be performed by means of the Telnet interface. After IP address entry to the Telnet interface it is possible to configure the router by the help of commands. The default IP address of the router is 192.168.1.1. Configuration may be performed only by the user "root" with initial password "root".

 A detailed description of the router settings via the Telnet interface can be found in the configuration manual.

## 7. Technical parameters

### 7.1. Technical parameters of router

LR77 v2		
Complies with standards		EN 301 511, v9.0.2, EN 301 908-1&2, v3.2.1, ETSI EN 301 489-1 V1.8.1, EN 60950-1:06 ed.2 + A11:09 + A1:10
Temperature range	Function Storage	-30 °C to +60 °C -40 °C to +85 °C
Protection	Freely In switch board	IP20 IP56
Supply voltage		10 to 30 V DC
Consumption	Reception GPRS LTE	300 mW to 3,5 W (GPRS transmission) to 5,5 W (LTE transmission)
Dimensions		42 x 76 x 113 mm (DIN 35 mm)
Weight		LR77 v2 – 150 g LR77 v2 SL – 280 g
Antenna connector		SMA – 50 Ohm
User interface	ETH USB PORT1 PORT2	Ethernet (10/100 Mbit/s) USB 2.0 type A host At customer's request At customer's request

Table 13: Technical parameters of router

### 7.2. Technical parameters of module

LTE module		
LTE parametry		bit rate 100 Mbps / 50 Mbps 3GPP rel. 8 standard supported bandwidth – 5Mhz, 10Mhz, 20Mhz
HSPA+ parameters		bit rate 21.1 Mbps/5,76 Mbps 3GPP rel. 7 standard UE CAT. 1 to 6, 8, 10, 12, 14 Data compress 3GPP
UMTS parameters		PS bitrate – 384/384 kbps CS bitrate – 64/64 kbps W-CDMA FDD standard
GPRS parameters		bit rate 236 kbps/236kbps GPRS multislot class 10, CS 1 to 4 EDGE multislot class 12, CS 1 to 4, MCS 1 to 9
Transmit power		UMTS/HSUPA/HSDPA/HSPA+ – (20dBm) EGSM 900 – Class 4 (33dBm) GSM 1800/1900 – Class 1 (30dBm)
Support channel		GSM/GPRS/EDGE – 900Mhz, 1800Mhz, 1900Mhz UMTS/HSDPA/HSUPA/HSPA+ – 900Mhz, 2100Mhz LTE – 800Mhz, 900Mhz, 1800Mhz, 2100Mhz, 2600Mhz

Table 14: Technical parameters of module

## 7.3. Technical parameters of processor

32b ARM microprocessor	
Memory	512Mb DDR SDRAM 128Mb FLASH 1Mb MRAM
Interface	Serial interface RS232 Ethernet interface 10/100Mbit/s USB 2.0 interface

Table 15: Technical parameters of processor

## 7.4. Technical parameters I/O port

Port IO		
Input/Output	Binary input	reed contact with trigger level 1,3 up to 1,4 V
	Binary output	120 mA/max. 30 V

Table 16: Technical parameters of I/O port

## 7.5. Technical parameters of expansion port

Technical parameters of the expansion ports are to be found in separate manuals for expansion ports.

## 8. Recommended literature

- [1] Conel: **Start guide**,
- [2] Conel: **Configuration manual**,
- [3] Conel: **User's manual – Expansion port RS232**,
- [4] Conel: **User's manual – Expansion port RS485/RS422**,
- [5] Conel: **User's manual – Expansion port M-BUS**,
- [6] Conel: **User's manual – Expansion port CNT**,
- [7] Conel: **User's manual – Expansion port ETH**,
- [8] Conel: **Application guide – Expansion port mounting**,
- [9] Conel: **Application guide – Programmer guide**.



## 9. Possible problems

Some network cards are able to be set in situation, when it is not possible to connect the router. It is possible to solve this problem in the following steps:

- hand by selection communication rates 10 MB/s in property network cards,
- connect router over switch,
- start computer only after finalizing the start of the router.



## 10. FAQ

- I can't get from internet on equipment, which is connected to router and I have NAT enabled.
  - *The device's gateway has to be configured as the router.*
- Router resets itself, connection on Ethernet fails.
  - *It is necessary to use an antenna, which will be situated far from power supply.*
- I don't get on web server at NAT.
  - *The remote http access of the router has to be disabled, default server address has to be your web server and the gateway of the web server has to be the IP of router.*
- PPP connection fails.
  - *Check signal power. If signal power is weak, you will have to use a better antenna. If the environmental cells have a similar signal it will be necessary to use a directive antenna. Signal levels have to be in the range -50dBm and -90dBm.*
  - *It is necessary to set ping, which will check the connection and, in the case of fail ping, restart connection.*
- PPP connection won't be established.
  - *Recheck GPRS settings - APN, name, password and IP address.*
  - *Try to enter PIN – verification if the SIM card hasn't set PIN code.*
  - *In private APN it is appropriate to switch the DNS server send off.*
  - *Switch log system on and observe where the error turns up.*
- Connection fails on Ethernet or connection isn't establishing.
  - *On ethernet interface of the router it is possible to switch auto negotiation off and set a rate and duplex by hand.*
- DynDNS not function.
  - *In private APN not functional.*
  - *If the same IP address is recorded in your canonic name as dynamically assign address, it means that the operator is using NAT or firewall.*
  - *NAT is possible to verify by the help of the ping on address of your server with static IP address and by the help of the router address verify and address in ping.*
  - *Firewall is possible to verify, for example by remote access on web interface.*
  - *The operator doesn't give out address DNS servers and without DNS server's it is impossible to connect to server dyndns.org. In log system will be this message:*
    - *DynDNS daemon started,*
    - *Error resolving hostname: no such file or directory,*
    - *Connect to DynDNS server failed.*
- IPSec tunnel is establishing but communication doesn't function.
  - *Probably it is badly set up route conditionals of connected equipment or it is bad set up GW.*
- FTP doesn't function.
  - *Router doesn't support the active FTP mode, supports the passive mode only.*

- RS232 doesn't function.
  - *It is necessary to verify present the expansion port RS232.*
  - *Verify present the expansion port RS232 in router configuration in menu „external port“, or verify connection locally by the help Telnet-Hyper terminal.*
- L2TP or IPSec isn't establishing.
  - *Verify the reason in the log system.*
- I switched the router to offline mode by the SMS message, but the router is in online mode after restart.
  - *Control SMS message doesn't change the router configuration. If the router is switched to offline mode by the SMS message the router will be in this mode up to next restart. This behaviour is the same for next all control SMS messages.*

## 11. Customers support

Up to date information about the product is on website:

<http://www.conel.cz/>

### Upkeep-advice:

- ⚠ The SIM-card must be handled carefully as with a credit card. Do not bend, do not scratch on this and do not expose to static electricity.
- ⚠ During cleaning of the router do not use aggressive chemicals, solvents and abrasive cleaners!

Conel Company hereby declares that the router narrated in this user's guide fits all basic demands of directive 1999/5/EC (R&TTE).

Router fits values of coefficient SAR defined by association ICNIRP and values of "About protection of health before non-ionized radiation".



Declaration about consistency was issued and is possible get it in accompanying CD or at producer.